



**AutoAnchor 710**  
**QUICK USER GUIDE**  
**Version 1.3**



# IMPORTANT INFORMATION

## READ BEFORE USING YOUR AUTOANCHOR

**This User Guide is intended as a quick reference for day to day use of the AA710. It must be read in conjunction with the Owner's Manual. The Owner's Manual has installation, set up and testing instructions plus information relating to troubleshooting and maintenance. If you do not have the Owner's Manual please contact your supplier or the manufacturer for a copy.**

## USER PRECAUTIONS

It is the owner's sole responsibility to ensure the AutoAnchor is installed, used and maintained in a manner that will not cause accidents, personal injury or property damage. When using the AutoAnchor the operator must use safe boating practices and safe windlass, anchoring and docking operation.

- **use the windlass or thruster strictly according to the manufacturer's instructions;**
- **only persons who are fully aware of the correct use of the thruster and windlass should be allowed to use the AutoAnchor to control this equipment;**
- **the user must personally control and supervise all anchoring and docking operations;**
- **the user must know the location of the main breaker or battery switch to disconnect the windlass or thruster from all power sources in the event of an emergency;**
- **the windlass or thruster power supply must be turned off when the equipment is not in use;**
- **there must be an alternative method available to operate the windlass or thruster;**
- **a failure of the wireless link will result in loss of control of the windlass or thruster via the AA710.**

### When Controlling a Windlass


- maintain a clear view of the windlass, rode and/or anchor during windlass operation;
- always ensure the anchor is fully docked and secured before moving the boat.

### When Controlling a Thruster

- do not operate close to swimmers, the powerful suction of water could cause serious injury;
- never run the thruster out of the water, this can cause serious damage to the motor;
- running a thruster without resistance from the propeller can also cause serious damage to the motor;
- if the thruster stops giving thrust while the motor is running, turn it off immediately.

The AutoAnchor manufacturer and supplier accept no liability for personal injury or property damage resulting from failure to follow the installation and operating instructions or the use of the AutoAnchor in a way that may cause accidents or damage or that may violate the law.

## AA710 BUTTONS




### To Turn the Auto Anchor On

Power up the AA702 base station.



Press the Mode button to turn the remote console on. There will be a delay of a few seconds while the remote console connects to the network. The screen will be locked and will display the last mode operated.



### To Turn the Auto Anchor Off




In the start screen press the Mode button to display the menu.



Scroll to Off.



Select Off.



OR




Press and hold the MODE button for 6 seconds.



**Note:** The AA710 remote console will automatically turn off after 4 minutes without use.

## INFORMATION DISPLAYED DURING OPERATION



### Battery Status

Displays the power left in the 2 x AA batteries in the remote console. To ensure full operational capacity do not allow the battery status to drop to zero. All settings and measurements are saved if the unit is turned off or if the battery fails. Refer to Part 5 Maintenance in the Owner's Manual for details on battery replacement and care.

## Signal Strength

This is the signal received by the remote console from the base station. It is affected by the distance between the two units and by structural aspects of the boat. Eg. A high concentration of steel superstructure between the base station and the remote console. If the base station is installed beneath a steel, carbon fibre or alloy deck it may not work.

## Backlighting

The backlighting turns on when the control buttons are touched. At all other times it is in power saving mode. The backlighting level is controlled by the light sensor fitted to the front of the AA710.

## Lock



Hold the Mode button for 2 seconds to unlock. The AA710 automatically turns off and resets the lock after 4 minutes without use.



### To reset the lock manually:


Press the Mode button to display the menu.



Scroll to Lock.



Select Lock. The screen will return to the current mode with the lock on.



## Changing Modes




Cycle through the modes by pressing the Mode button for 1 second at a time



### OR

Press and release the Mode button to access the menu.

Select the Mode.



## WINDLASS OPERATION WITH THE AA710

For an accurate reading always ensure the AutoAnchor display reads 0.0 before deploying the anchor. See Clear to Zero page 32.

Counting continues if the AA710 remote console is turned on and if the windlass is operated by another control eg foot switches.



## AUTOMATIC OR MANUAL OPERATION

Keep your finger on the button to deploy the anchor manually or use the automatic function for hands free anchor deployment and retrieval. See the instructions for both options below.

## MANUAL OPERATION

### Deploy and Retrieve the Anchor Using Manual Operation



Turn the AutoAnchor on.



Clear the safety lock.



Press and hold the Down button to deploy the anchor and the Up button to retrieve the anchor.

Release the button to stop the windlass operation. Ensure the anchor is fully docked and secured before moving the boat.



**DOCKING ALARM:** During retrieval the AutoAnchor beeps to warn the operator the anchor has passed the preset docking distance. Extra care must be taken at this time.

## AUTOMATIC WINDLASS OPERATION



**WARNING:** There is an inherent risk when using any automatic function on a boat. If you choose to use the AutoAnchor automatic functions, you must still control and supervise all windlass and anchoring operation.

Use the Automatic Function to:

- Preset the length of rode for deployment;
- Have hands-free operation of the windlass;
- Retrieve the anchor automatically to the preset docking distance.

Note: For rope/chain counting, if the sensor or load sensing wires are not installed correctly the automatic function **will not operate**. An Installation warning message will display on the screen. The windlass can still be operated using manual operation but the AutoAnchor will not count accurately.







### Safety Override



**Press any button on the AutoAnchor to stop the windlass during automatic release or retrieval. In an emergency shut off the power to the windlass using the isolating/breaker switch.**

### Enable Automatic Operation

A “rode to be released” value must be entered to use automatic operation.





#### To Set A Rode to be Released Value

-  Turn the AutoAnchor on.
-  Clear the safety lock.
-  Press the Mode button to enter the menu.
-  Press the Mode button twice to enter Set auto.
-  Scroll up or down to the value.
-  Save and return to start screen.






**To disable automatic operation: Set the rode to be released value to Off.**


#### Deploy the Anchor Using Automatic Operation

-  Turn the AutoAnchor on.
-  Clear the safety lock.
-  Press the Mode button to enter the Menu.
-  Press the Mode button again to select Auto. The screen displays the current length for Auto release. If this setting is correct, press and release the down button to deploy the anchor.







#### To Change the Setting:

-  Press the Mode button again to select Set auto.
-  Scroll to the value.
-  Save and return to Auto.


The windlass will stop and the AutoAnchor will beep when the preset length of rode has been released. The screen will display “Target reached”.




## Retrieve the Anchor Using Automatic Operation

-  Turn the AutoAnchor on.
-  Clear the safety lock.
-  Press the Mode button to enter the Menu.
-  Press the Mode Button again to select Auto.
-  Press and release the Up button to retrieve the anchor. The windlass will stop and the AutoAnchor will beep when the docking distance is reached. The screen will display Docking distance.
-  Press and hold the Up button to complete retrieval of the anchor. The AutoAnchor will beep during this process.

**Ensure the anchor is fully docked and secured before moving the boat.**












## OTHER WINDLASS OPERATION SETTINGS

Press  to access the Menu when the AutoAnchor is turned on.

### To Clear to Zero






The AutoAnchor must be turned on.



-  Press to access the Menu.
-  Scroll to Clear to Zero
-  Select Clear to zero.
-  Select No/Yes.
-  **Yes** - return to start screen.
-  **No** - return to the menu, then press  again to return to the start screen.





### To Check Logs

The AutoAnchor must be turned on.

-  Press to access the Menu.
  -  Scroll to Logs.
  -  Select Logs.
  -  Return to the menu.
  -  Exit and return to start screen.
- Logs can be cleared if base station is reset.



### To Use the Deckwash and Decklight

-  Use the Left arrow to turn the decklight on and off.
  -  Hold down the Right arrow to use the manual deck wash.
- To enable the deckwash or decklight, refer to Set Up.



**Note: If Auto wash is set it will turn on automatically during retrieval if any windlass control is used. Control could be via the AA710 and also foot switches, toggle switches or another AutoAnchor unit.**

# THRUSTER OPERATION WITH THE AA710




The AA710 can control a single bow thruster or a bow and stern thruster together.



## USER PRECAUTIONS

Only persons who are fully aware of the requirements for safe operation of the thruster should be allowed to use the AA710 to operate this equipment. The owner of the boat must take responsibility for ensuring the thruster is used according to the manufacturer's instructions and with the appropriate safety precautions.






The thruster must not be operated close to swimmers, the powerful suction of water could cause serious injury. Never run the thruster out of the water as this can seriously damage the motor. Running a thruster without resistance from the propeller can also cause serious damage to the motor. If the thruster stops giving thrust while the motor is running, turn it off immediately. Always turn off the power to the thruster when it is not in use.


### To Access the Thruster

-  Turn the AutoAnchor on.
-  Clear the safety lock.
-  Cycle through the modes by pressing the Mode button for 1 second at a time




**OR**


-  Access the Menu.
-  Scroll to "Select Mode".
-  Select "Select Mode".
-  Scroll to Thruster.
-  Select Thruster.



### Thruster System Locks





AA710 System locked.  
Hold Mode button to clear.




Local lock on. No access from AA710.  
Thruster operated by another controller.

### Bow Thruster Operation


-  Use the left and right arrow buttons to control the thruster operation.  
Left to port and and right to starboard.



Bow thruster selected.  
System powered up and idle.



Thrust to port.




Thrust to starboard.


## Combined Bow and Stern Thruster Operation

- △ If there is a bow and a stern thruster fitted, use the up button to toggle between the bow thruster and the combined bow and stern thruster.
- ▽ Use the down button to toggle between the stern thruster and the combined bow and stern thruster.
- ◁▷ Use the left and right arrow buttons to control the thruster operation to port and starboard.


## Dual Thruster Operation



Bow and stern thrusters selected. System powered up and idle.




Bow and stern thrusters to port.




Bow and stern thrusters to starboard.


## Bow Thruster Operation



Bow thruster selected. System powered up and idle.




Bow thrusting to port.




Bow thrusting to starboard.


## Stern Thruster Operation



Stern thruster selected. System powered up and idle.



Stern thrusting to starboard.




Stern thrusting to port.

## Pivot (360° Turn) Operation

Pivot mode can be selected from any thruster operation mode, by pressing the Up button for more than 1 second. For example:

Bow thruster selected. System powered up and idle.



△ Hold the Up button for more than 1 second to change to Pivot Mode.



◀▶ Use the left or right buttons to turn the boat clockwise or anticlockwise.

▶ Clockwise.


A top-down diagram of a boat in Pivot Mode with a large black arrow indicating a clockwise rotation. The boat is centered, with a left-pointing arrow and a right-pointing arrow. In the bottom-left corner, there is a small icon of a person and a bar graph. In the bottom-right corner, there is a battery level indicator.

◀ Anticlockwise.


A top-down diagram of a boat in Pivot Mode with a large black arrow indicating an anticlockwise rotation. The boat is centered, with a left-pointing arrow and a right-pointing arrow. In the bottom-left corner, there is a small icon of a person and a bar graph. In the bottom-right corner, there is a battery level indicator.

△▽ To exit pivot mode and return to single thruster operation press the up or down button.

△ Press the up button to return to bow thruster operation.



▽ Press the down button to return to stern thruster operation.






# AUXILIARY EQUIPMENT OPERATION WITH THE AA710

The AA710 can control other equipment on the boat such as pumps, davits or cleats using the auxiliary outputs.






## USER PRECAUTIONS




Only persons who are fully aware of the requirements for safe operation of the auxiliary equipment should be allowed to use the AA710 to operate this equipment. The owner of the boat must take responsibility for ensuring the equipment is used according to the manufacturer's instructions and with the appropriate safety precautions.

### To Access the Auxiliary Mode

-  Turn the AutoAnchor on.
-  Clear the safety lock.  
Depending on the system set up.
-  Cycle through the modes by pressing the button for 1 second at a time.

OR

-  Tap to access the Menu.
-  Scroll to "Select Mode".
-  Select "Select Mode".
-  Scroll to Auxiliary.
-  Select Auxiliary.



On the console use the key shown on the screen to operate the Auxiliary output. The Auxiliary output will be highlighted on the screen when it is selected or active.



FCC, CE and compliance statements are set out in the Owner's Manual

To the best of our knowledge the information in this User Guide was correct at the time of printing. However, the AutoAnchor is continuously being reviewed and improved and product specifications may be changed without notice. The latest product specifications may not be reflected in this version of the manual.

Documentation relating to the AutoAnchor is created in the English language and can be translated from English to another language. In the event of any conflict between translated documents, the English language version will be the official version.

All AutoAnchor documents including the Owner's Manual are also available on the website [www.autoanchor.co.nz](http://www.autoanchor.co.nz)

---

AutoAnchor products are designed and manufactured by:

RMSD Limited

Street Address: 46 Lake Road  
Northcote  
Auckland 0627  
New Zealand

Postal Address: P O Box 36 489  
Northcote  
Auckland 0748  
New Zealand

Telephone: +64 9 419 1219  
Facsimile: +64 9 419 1931  
Email: [info@autoanchor.co.nz](mailto:info@autoanchor.co.nz)  
Website: [www.autoanchor.co.nz](http://www.autoanchor.co.nz)

Copyright 2008 © RMSD Limited, New Zealand  
AutoAnchor is a trademark of RMSD Limited

