

AutoAnchor 550/150 Magnet & Sensor Installation

Lofrans Project 1000/1500 Windlass with Rope/Chain Rode

Magnet:

The Lofrans Project 1000/1500 chainwheels are predrilled for magnet installation. Invert the chainwheel in the windlass so that the magnet hole is in the top of the chainwheel.

i.e. The rope/chain rode must pass between the magnet and the sensor.

Sensor:

These windlasses are predrilled to fit the sensor when using an all chain rode. This position is not suitable for a rope/chain rode. Follow the diagram below to locate the correct position for the AutoAnchor 550 sensor when using a rope/chain rode. Drill a 13/32" (10mm) hole through the windlass deck plate.

